



### INSTALLATION INSTRUCTIONS

1. LOCATE EXHAUST PORT ON MUFFLER IF PRESENT REMOVE SPARK ARESTOR SCREEN
2. PLACE EXHAUST EXT. COUPLING THROUGH THE MUFFLER SHROUD MAKING SURE THE BACKING NUT IS PRESENT ON FRONT SIDE
3. THREAD THE SECOND BACKING NUT ONTO THE COUPLING BEFORE THE EXT. IS PLACED INTO THE MUFFLER PORT
4. TIGHTEN THE BACKING NUT SNUG TO THE MUFFLER SHROUD MAKING SURE AS MUCH EXHAUST EXT. AS POSSIBLE IS IN THE MUFFLER PORT
5. QUICK COUPLE THE EXHAUST HOSE TO THE COUPLING FOR REDUCTION IN CARBON MONOXIDE INTO THE AIR STREAM
6. MAKE SURE THE EXHAUST TUBE IS AS FAR FROM THE FAN AND TO ONE SIDE AS POSSIBLE

**WARNING: THIS EXHAUST EXT. DOES NOT COMPLETELY REDUCE ALL THE CARBON MONOXIDE AND FUMES FROM THE FAN OR AIR STREAM**

**UNIFIRE**